

GFP Heat pipe ASSY

Test configuration in JAXA/ISAS

Logger No. 1


Temperature of the heat pipe tube,
coupler, ambient and reservoir.

Channel number of logger means the number in red circle


87	CH77	CH77	DC	50V	Off	200	-200 V																		
88	CH78	CH78	DC	50V	Off	100	-100 V																		
89	CH79	CH79	DC	50V	Off	200	-200 V																		
90	CH80	CH80	DC	50V	Off	200	-200 V																		
91	Logic/Pul:Off																								
92	測定値																								
93	番号	日付 時間	ms	CH1	CH2	CH3	CH4	CH5	CH6	CH7	CH8	CH9	CH10	CH11	CH12	CH13	CH14	CH15	CH16	CH17	CH18	CH19	CH20	CH21	CH22
94	NO	Time	ms	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C
95	1	2020/12/3 11:17	0	-46.6	-50.1	-50.3	-50.4	-50.5	-50.2	-49.5	-45.8	-16.3	-3.8	-24.3	-53.8	-54.7	-56.5	-55.4	-49.9	-50.5	-51	-51.1	-51.3	-50.3	
96	2	2020/12/3 11:17	0	-46.6	-50.1	-50.3	-50.3	-50.5	-50.2	-49.4	-45.7	-16.3	-3.7	-24.3	-53.8	-54.7	-56.5	-55.4	-49.9	-50.4	-51	-51	-51.3	-50.3	
97	3	2020/12/3 11:17	0	-46.5	-50.1	-50.3	-50.3	-50.5	-50.1	-49.5	-45.7	-16.2	-3.7	-24.4	-53.8	-54.8	-56.5	-55.4	-49.9	-50.5	-51	-51.1	-51.3	-50.3	
98	4	2020/12/3 11:17	0	-46.6	-50.1	-50.3	-50.3	-50.5	-50.1	-49.5	-45.7	-16.4	-3.8	-24.4	-53.8	-54.8	-56.5	-55.4	-49.9	-50.5	-51	-51.1	-51.3	-50.3	

Tube	Tube on Radiator	Coupler for connecting the heat pipe tube and Al frame	Cold plate and liquid in the chiller loop
------	------------------	--	---

Thermocouple number is the number of thermocouple shown in following slide


[illegible]

Loop1




Channel number of logger	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
Loop number	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
Thermocouple number	h1	h2	h3	h4	h5	h6	h7	h8	h9	h10	R1	R2	R3	R4	R5

Loop6



Channel number of logger	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30
Loop number	6	6	6	6	6	6	12	12	12	12	12	12	12	12	12
Thermocouple number	h11	h12	h13	h14	h15	h16	h17	h18	h19	h20	R6	R7	R8	R9	R10


Loop12



Tube on radiator plate




Loop6



Channel number of logger	46	47	48	49	50	51	52	53	54	55	56								
Loop number	6	6	6	6	6	6	6	6	6	N/A	N/A								
Thermocouple number	c1	c2	c3	c4	c5	c6	c7	c8	c9	N/A	N/A								

Chiller loop and cold plate




Channel number of logger	57	58	59	60	61	62	63	64	65	66	67	68	69	70	
Loop number	Cold plate surface temperature										Liquid temperature in chiller circulation loop				
Thermocouple number	C1	C2	C3	C4	C5	C6	C7	C8	C9	C10	C11	C12	C13	C14	

Channel number of logger	71	72	73	74	75	76									
Loop number	Reservoir	Room temperature	N/A	Sub-heater surface											
Thermocouple number			N/A												

Logger No. 2

Temperature of the aluminum plate
(Opposite corner of the coupler)


For every aluminum plate, the thermocouple was attached to the edge of the aluminum plate at the opposite corner where the coupler was attached.




Top view of the aluminum plate

NOTE: Additional thermocouples were attached around the coupler for loop no.6 to measure the temperature in detail. (Page 8)

Position of the thermocouple



Top view



Side view

The number of the thermocouple on loop No.1 is shown as an example. The number was counted from the bottom to the top layer.